USER'S MANUAL OF SPORTS WATCH CAMERA DVR

SKU: HC153 http://safestmonster.com/waterproof-watch-camera-motion-detection.html

Package includes:

1 x Wrist watch camera DVR
1 x Wall Charger
1 x USB cable
1 x Driver CD
You get 1 year warranty for this product.

I. Introduction to the Watch Camera:
II. Quick Start
III. Operation Guidance:
IV. Question and Answers:
V. Cautions

I. Introduction to Digital Camera Watch

You can use watch DVR to shoot high-definition video, taking high-quality photos, recording high-quality audio in any conditions even underwater. With simple operation, elegant design, small size,it is easy to carry.

II. Quick Start

Step 1: Make sure the battery is full to start the Watch Camera. Then switch the button 4 for 3 seconds. The watch would be stand by to use.

Step 2: Record Videos: In model-standing by. Press button 4 a time. It starts to record video. Press button 4 again. It stops recording and stand by again.

Step 3: Voice Recording: Press Button 6 for 3 seconds in condition standing by. It starts to record voice. Press again for 1 time, it saves the file and stand by again.

SAFESTMONSTER USER'S MANUAL. ALL RIGHTS RESERVED.

Step 4: Taking picture: Press button 6 in condition standing by for a time. The led flashes in red one time. It means taking one picture, save file and stand by again. Making sure the storage of the memory is enough before using it.

Note: In condition standing by, it will be off automatically if there is no any operation.

III. Operation Guidance

a) When you use it as a PC camera. Please install the camera drive first if you use it for the first time. Then press the button 6 and connect it to your PC in condition being off.

b) Fault Treatment: When the camera can not be on. Please recharge the battery to be full and then turn it on. When the power is poor. The blue led flash quickly. The camera will save the file automatically and then turn off. When there is no enough space in the memory. The red led would flash quickly and turn off in 5 seconds. Reset the camera with pressing the button 4 & button 6 at the same time.

IV. Questions and Answers

1, Battery: If you don't use the DVR for long period. Please recharge the battery to be full before using it.

2, You can not use it in water. The waterproof function just prevent the water drops into the watch in normal life. When you can not download file or upload the file. Please check if the PC and drive connector correctly.

V. Cautions

Please don't use it in water, thick dust environment. Avoid strong hit to hard objects.

Thanks for reading and happy ecommerce!

SAFESTMONSTER USER'S MANUAL. ALL RIGHTS RESERVED.